

ORIGINAL INSTRUCTIONS - according to Directive 2006/42/EC, Annex I 1.7.4.1

OPERATOR'S MANUAL

Z 8805

Tedder

FOREWORD

DEAR CUSTOMER!

We appreciate the confidence you have shown to our company by investing in a KONGSKILDE product and congratulate you on your new purchase. Of course, it is our wish that you will experience complete satisfaction with the purchase investment.

This instruction manual contains information about correct and safe use of the machine.

When buying the machine you will receive information about use, adjustment and maintenance.

However, this first introduction cannot replace a more thorough knowledge of the different tasks, functions and correct technical use of the machine.

Therefore you should read this instruction manual very carefully before using the machine. Pay special attention to the safety instructions.

This instruction manual is made so that the information is mentioned in the order you will need it, i.e. from the necessary operation conditions to use and maintenance. In addition, there are illustrations to accompany the text.

"Right" and "Left" are defined from a position behind the machine facing the direction of travel.

All the information, illustrations and technical specifications in this instruction manual describe the latest version at the time of publication.

Kongskilde Industries A/S reserves the right to make changes or improvements in the design or construction of any part without incurring the obligations to install such improvements on any unit previously delivered.

FOREWORD	3
1. IN GENERAL	7
INTENDED USE	7
FORESEEABLE MISUSE.....	8
General safety instructions.....	8
TECHNICAL DATA.....	9
Manufacturer's address.....	9
Certificates	9
Marking of the machine.....	9
General technical data	11
2. SAFETY	12
MARKING OF SAFETY INSTRUCTIONS IN THE INSTRUCTION MANUAL.....	12
SAFETY RULES AND ACCIDENT PREVENTION.....	13
Power take-off	15
Tyres	16
Working near high-voltage lines	16
Maintenance	17
Placement of reference signs on the machine	19
3. MOUNTING OF THE MACHINE AFTER DELIVERY.....	21
ADJUSTMENT OF PTO DRIVE SHAFT.....	25
MOUNTING OF OPTIONAL EQUIPMENT	26
Support wheel	26
Anti-wrapping plate	27
Night swath gearbox	27
FUNCTIONAL TEST.....	28
4. MOUNTING OF THE TEDDER / PREPARATION	29
SPECIAL INSTRUCTIONS.....	29
PREPARATION OF TRACTOR.....	30
3-point suspension on the tractor	30
Placement of cord	31
Hydraulic system (restriction).....	31
Electric system	31
CONNECTION OF THE ROTARY TEDDER TO THE TRACTOR.....	31
Connection to the link arms and top link of the tractor	31
Hydraulic connection.....	33
Connection of lighting equipment.....	33
Connection of PTO shaft.....	34
DISCONNECTION AND PARKING OF THE ROTARY TEDDER	35
TRANSPORT ON PUBLIC ROADS.....	36

5. HANDLING OF THE TEDDER DURING WORKING	37
CONVERSION OF THE TEDDER FROM TRANSPORT TO WORKING POSITION	37
Release of the transport safety bolt	37
Opening of hydraulic stop valves	38
Unfolding the machine in working position	38
STARTING THE ROTOR	38
POSITION WHEN DRIVING ON HEADLANDS	39
SPREADING FROM FENCE	39
CONVERSION OF THE TEDDER FROM WORKING TO TRANSPORT POSITION	41
Folding to transport position	41
Closing of hydraulic stop valves	42
Activating the transport safety bolt	42
6. BASIC ADJUSTMENT OF THE TEDDER	44
ADJUSTMENT OF WORKING DEPTH	44
ADJUSTMENT OF THE WORKING DEPTH WITH EXTRA SUPPORT WHEEL (OPTION)	45
ADJUSTMENT OF SPREADING ANGLE	45
ADJUSTMENT OF SHOCK ABSORBER	47
WORKING SPEED AND NUMBER OF REVOLUTIONS	48
Driving speed and number of revolutions	48
Spreading of mown swaths	48
Tedding	48
Spreading of swaths	49
Night swaths	49
7. SERVICE AND MAINTENANCE OF THE TEDDER	50
SAFETY RULES	50
GENERAL MAINTENANCE INSTRUCTIONS	50
CLEANING OF THE MACHINE AND PREPARATION FOR WINTER STORAGE	50
Cleaning of the machine	50
Placement of the machine in the open	51
Winter storage	51
WHEELS	51
Tyre pressure	51
PTO SHAFTS	52
Instructions regarding PTO shafts:	52
HYDRAULIC SYSTEM	52

8. MAINTENANCE - GREASE CHART	53
PTO SHAFT	53
GEARBOXES	54
GREASE SPOTS ON THE TEDDER	56
Joints.....	56
Oblong hole (guide).....	57
Headstock	58
Transport safety bolt	58
GREASE CHART OVERVIEW	59
9. MACHINE DISPOSAL.....	60
10. SUPPLEMENT	61
11. WARRANTY.....	63

1. IN GENERAL

This instruction manual contains important information concerning operation, maintenance and adjustment of the machine. Furthermore, all safety instructions are mentioned and emphasized. Read the instruction manual carefully before using the machine. The instruction manual should be accessible for the operator.

All safety instructions must be observed.

INTENDED USE

- The rotary tedder is intended for tedding, swath spreading and producing night swaths of straw crops on the ground.
- The rotary tedder is solely constructed for usual work in agriculture.
- The rotary tedder should only be connected to a tractor and driven by the PTO of the tractor.
- Any other use is regarded as not intended. The manufacturer is not responsible for any damage resulting from such use; the user bears that risk.
- Intended use also implies that the instructions and rules prescribed by the manufacturer are observed.
- The rotary tedder should only be used, maintained and repaired by persons who, through relevant instructions and after reading the instruction manual, are familiar with the machine and, in particular, are informed of possible dangers.
- The following safety instructions as well as common rules concerning technical safety, working practices and road safety must be observed altogether.
- If changes are made on the machine and its construction without permission from the manufacturer, the manufacturer cannot be held responsible for any damage resulting from this.
- Intended use also implies that the rules prescribed by the manufacturer concerning operation, maintenance and service are observed.

FORESEEABLE MISUSE

- Sweeping of e.g. farmyards with the rake tines or brooms fastened to these is not allowed. There is a risk that e.g. stones are thrown out from the working area of the machine with danger of personal injury or damage to objects.
- Any use beyond the intended use is regarded as foreseeable misuse.

GENERAL SAFETY INSTRUCTIONS

The following is a brief description of the measures, which should be a matter of common knowledge to the operator.

1. Always disengage the PTO drive shaft, activate the parking brake and stop the tractor engine before you
 - lubricate the machine,
 - clean the machine,
 - maintain the machine.
 - adjust the machine.
2. Always use the transport lock when transporting the machine.
3. Never work under a raised rotor unless it is secured by means of stop blocks or other mechanical securing devices.
4. Always block the tractor wheels before working on the machine.
5. Never start the tractor until all persons are at a safe distance away from the machine.
6. Make sure that all tools have been removed from the machine before starting the tractor.
7. Make sure that all guards are intact and have been mounted correctly.
8. The clothes of the operator must be tight-fitting. During work never wear loose clothes or have your hair hang down as it may be pulled in by the moving parts of the machine.
9. Always drive with the statutory lights and safety marking during transport on public roads and at night.
10. Do not stand near the machine while it is working.
11. When mounting the PTO drive shaft, check that the number of rpm and the direction of rotation of the tractor match those of the machine.
12. Before raising or lowering the machine, check that no persons are near the machine or touching it.
13. Do not stand near the safety frames of the rake until all revolving parts have stopped moving.
14. Never use the machine for other purposes than what it has been constructed for.
15. Do not allow any children to be near when you are working with the machine.
16. Never stand between the tractor and the machine during connection and disconnection.

TECHNICAL DATA

MANUFACTURER'S ADDRESS

Kongsilde Industries A/S
Lindeallé 7
DK-6400 Sønderborg – Denmark
Phone.: +45 7412 5252

CERTIFICATES

-EC-Declaration of conformity (see page 62)

MARKING OF THE MACHINE




Fig. 1-1

Fig. 1-1 The machine data is printed on the machine plate. The machine plate is placed in the right-hand side in the direction of travelling behind the suspension at the frame.



The marking on the machine should neither be changed nor removed!

The information on the machine plate can be written below so that it is always at hand.

1. IN GENERAL

Machine type

Serial number

Manufacturing year

In case of service questions and when ordering spare parts, please state machine type, serial number and manufacturing year so that the inquiry can be treated as soon as possible.



Only use original KONGSKILDE spare parts. The manufacturer cannot be held responsible for any damage resulting from the use of non-original spare parts.

1. IN GENERAL

GENERAL TECHNICAL DATA

Technical data	Z 8805
Rotor diameter	1.50 m
Number of rotors	8
Double tines per tine arm:	6
Working width, max:	8.80 m
Minimum transport width:	2.95 m
Parking height	3.25 m
PTO rpm	540 rpm
Link arm category	II
Suspension type	3-point
Power requirement	from 60/82 kW/HP
Wheel, rotor	16x6,50-8 (6PR) 18,5x8,50-8 (6PR)
Oil outlets	1 single acting 1 double acting
Electricity (for extra lighting kit)	12 V
Equivalent sound pressure level	under 70 dB (A)
Weight, approx.	1320 kg




Fig. 1-2

Fig. 1-2 Z 8805

2. SAFETY

MARKING OF SAFETY INSTRUCTIONS IN THE INSTRUCTION MANUAL

In this instruction manual this symbol is used with reference to personal safety directly and indirectly through maintenance of the machine.



This symbol (safety marking according to DIN 4844-W9) is supplemented with the following references:

General references are marked with this symbol:



Reference signs on the machine must be observed and kept in a readable condition.

SAFETY RULES AND ACCIDENT PREVENTION

1. The safety instructions in this manual together with common rules concerning safety and accident prevention must be observed!
2. The warning and reference signs provide important information on safe operation and should be observed!
3. When driving on public roads the current safety rules must be observed!
4. Before working with the machine you should make yourself familiar with all devices, operating elements and functions. During work this will be too late!
5. The clothes of the operator must be tight-fitting. Avoid loose clothes.
6. The machine should always be kept clean! Hereby you avoid danger of fire.
7. Always check the area around the machine before working, especially for children! Make sure that your view is sufficient!
8. Never allow anybody to be on the machine during work and transport.
9. The machine must be connected as per instructions and should only be secured/fastened at the prescribed devices!
10. During connection and disconnection the supports must be in the prescribed positions!
11. Particular care is required during connection and disconnection of machines!
12. The limits for allowable axle load, total weight and transport dimensions must be observed!
13. Transport equipment, e.g. lighting and warning kit as well as protection equipment must be checked and fitted.
14. Operating parts (cords, chains, rods etc.) for remote control equipment must be placed so that they do not cause unintended movements in transport and working position.
15. For road transport the machine must be prepared and locked according to the instructions of the manufacturer!
16. Never leave the tractor seat when driving!
17. Always adjust the driving speed to the conditions of the ground. When driving up and down and across hillsides, sharp turns should be avoided!

2. SAFETY

18. Driving, steering and braking capacity are influenced by mounted or trailed implements and ballast weights. Therefore please be aware of sufficient steering and braking capacity!
19. When turning pay attention to the overhang and oscillating weight of the machine!
20. Only use the machine if all guards are mounted correctly!
21. Nobody should be allowed to stand in the working area!
22. Do not stand in the turning and swivel area of the machine!
23. Hydraulically foldable and pivotal frames should only be activated when there are no persons in the swivel area!
24. Do not allow any person to stand under a raised machine when the machine is not in locked position!
25. At remote-controlled (e.g. hydraulically controlled) units may be places where there is danger of injury!
26. Lower the machine to the ground, stop the engine and remove the ignition key before leaving the tractor!
27. Never stand between the tractor and the machine without securing the vehicle by means of the hand brake and/or stop blocks!
28. Always stop the operation of the tedder when leaving the tractor seat.

2. SAFETY

POWER TAKE-OFF

1. Only use the PTO drive shafts prescribed by the manufacturer!
2. The protection tube and cover of the PTO and the PTO guard – also on the machine side – must be mounted and undamaged!
3. The tube overlap of the PTO shaft must be correct in transport and working position!
4. Always stop the PTO and the tractor engine and remove the ignition key before connecting or disconnecting the PTO drive shafts.
5. When using PTO shafts with overload or freewheel clutch which is not covered by the protective devices of the tractor, the overload/freewheel clutches must be placed on the machine side!
6. Always make sure that the PTO drive shaft has been mounted and secured correctly!
7. The guard of the PTO shaft is secured with the chain!
8. Before starting the PTO check that the number of RPM of the tractor PTO matches the number of RPM of the machine.
9. When using a travel speed controlled PTO, be aware that the number of rpm is depending on the travel speed and that the direction of rotation will change when backing!
10. Before starting the PTO check that there are no persons in the danger zone of the machine!
11. Never connect the PTO if the engine has stopped!
12. When working with the PTO make sure that no persons stand near the rotating PTO shaft.
13. Always stop the PTO if the deviation is too big or PTO is not used!
14. Caution! When the PTO has been stopped there will be a momentum! Do not get too close to the machine. Do not carry out any work on the machine until it has come to a complete stop!
15. Cleaning, greasing and adjustment of a PTO-driven machine or PTO shaft should only take place when the PTO has been disconnected, the engine stopped and the ignition key removed!
16. When the PTO shaft is disconnected from the tractor it must be fastened to the suspension with the chain!
17. If the PTO shaft is damaged it must be repaired immediately before working with the machine!

2. SAFETY

TYRES

1. Before working on the tyres ensure that the machine is stable and cannot move (by means of stop blocks)!
2. Mounting of wheels requires sufficient knowledge and correct mounting tools!
3. Repair of tyres and wheels should only be made by experts and with correct mounting tools!
4. Check the tyre pressure regularly! Observe the prescribed tyre pressure!

WORKING NEAR HIGH-VOLTAGE LINES

1. Be very careful if working under or near high-voltage lines.
2. Make sure that the total height is as low as possible if working or transporting the machine near high-voltage lines.
3. If driving under overhead lines the driver must contact the owner of the overhead lines in order to get information on the rated voltage and minimum height of the overhead lines.
4. The safety distances in the table must be observed.

Rated voltage		Safety distance from overhead lines
KV		M
Up to	1	1
Over	1 to 110	2
Over	101 to 220	3
Over	220 to 380	4

2. SAFETY

MAINTENANCE

In general:



When repairing or maintaining the machine it is especially important to ensure correct personal safety. Therefore, always park the tractor (if mounted) and the machine according to the GENERAL SAFETY RULES, chapter 2, in the beginning of this instruction manual.

Screws and bolts on your new machine must be retightened after 5 hours of operation. This also applies if repairs have been made.

Ma Ø	Class: 8.8 MA [Nm]	Class: 10.9 MA [Nm]	Class:12.9 MA [Nm]
M 8	25	33	40
M 10	48	65	80
M 12	80	120	135
M 12x1,25	90	125	146
M 14	135	180	215
M 14x1,5	145	190	230
M 16	200	280	325
M 16x1,5	215	295	350
M 18	270	380	440
M 20	400	550	650
M 20x1,5	430	615	720
M 24	640	900	1100
M 24x1,5	690	960	1175
M 30	1300	1800	2300

Torque measurement **MA** (if nothing else has been stated).

2. SAFETY



1. Maintenance, service, cleaning and repair must only take place when the PTO and the engine have been stopped! - **Remove the ignition key!** - Apply the hand brake of the tractor or secure the tedder so that it cannot move!
2. Screws and nuts must be checked regularly and re-tightened if necessary!
3. If maintenance is going to be made on a machine in raised position, always secure it by means of appropriate supports!
4. Oil and grease are disposed of as prescribed!
5. Disconnect the power before working on the electric system!
6. If guards are exposed to wear they must be checked regularly and replaced in time!
7. Before carrying out electric welding on tractor and mounted machine the cable for alternator and battery must be dismantled.
8. Spare parts must at least correspond to the technical requirements prescribed by the manufacturer! Original spare parts observe these requirements!

PLACEMENT OF REFERENCE SIGNS ON THE MACHINE

The reference signs are warning of dangers of the machine. The safety references must be observed at any time. Reference signs must be kept clean and in a readable condition. Damaged or missing safety signs must be ordered from your dealer as spare parts and must be placed at the correct positions!

1. Read the instruction manual and the safety instructions carefully before using the machine, and observe the instructions!
2. Always stop the PTO and the tractor engine and remove the ignition key before maintaining, repairing and servicing the machine!
3. Do not touch the machine until the rotating parts have come to a complete stop!
4. Keep a safe distance to the rotating parts of the machine! When the engine is running, there is a risk of parts being thrown out.
5. Never move your hand into the danger zone as long as the parts can move! This may cause serious injury and, at worst, result in death!
6. During operation, the locking bolt must be pulled out. During transport the locking bolt must be pushed in.
7. The prescribed maximum number of rotations and direction.
Reference to the minimum overlap on the profile tubes and the minimum distance in order not to bottom the shaft out.
8. The pressure tank is under gas and oil pressure.
9. Make sure that there are no persons in the swivel area of the boom arms! Keep a safe distance!
10. Warning panel, reflecting.
11. Yellow reflector (at the side when the boom arms are folded up).
12. Decal tyre pressure

2. SAFETY



3. MOUNTING OF THE MACHINE AFTER DELIVERY



- Mounting of the rotary tedder must only be carried out by experts.
- The necessary tools and adjustment tools must be available.
- After mounting a complete functional test of the machine must be carried out.
- After 5 hours of operation all screw joints must be re-tightened!

The rotary tedder Z 8805 is separated into parts and delivered on a pallet.

For shipment on a big pallet the middle support wheels and some arms are dismantled.

Loose parts such as a bag with small parts (screws) and the PTO shaft have been tied to the pallet or the machine in order to save space.

Transport of the tedder on pallet.




Fig. 3-1

Fig. 3-1 Lift and transport of the rotary tedder which is packed on a pallet must only be carried out with a fork-lift truck, crane, hoist or front loader.

Loading device with 3 chains is fastened to the points HL, HR and VM (3-point suspension).



Transport of the rotary tedder delivered on a pallet is only allowed with a fork-lift truck with forks that are minimum 1500 mm. Do not under any circumstances use fork-lift truck with shorter forks.

3. MOUNTING OF THE MACHINE AFTER DELIVERY

Transport should only take place on even, firm ground at low speed and low lifting height.




Fig. 3-2

Fig. 3-2 Connection of the pre-mounted machine from the pallet: The mounting order below must be observed!

1. All loose machine parts which have been tied to the machine or the pallet are removed.
2. For connection of the rotary tedder to the 3-point linkage of a tractor the 3-point linkage must be placed at the required height (lowest 3-point connection pin approx. 350 mm above the ground). The machine with pallet is raised and placed on a platform or ramp which is approx. 250 mm high.

3. MOUNTING OF THE MACHINE AFTER DELIVERY

If you have no platform, you can use a front loader with chain to carefully raise the rotary tedder at the 3-point linkage at front and tip it backwards so that a support can be placed beneath in order to obtain the necessary height (lowest 3-point connection pin approx. 350 mm above the ground) for connection to the 3-point linkage. Before the tedder is tipped, the rear parking stand is placed in a safety support position and the clearance which is necessary for tipping is specified.

3. Connect the machine to the 3-point suspension of the tractor.
4. Connect hydraulic hoses and electric plugs to the tractor.
5. Raise the machine a little.
6. The left and right boom arms are folded out slowly by means of the tractor hydraulics.
7. All support wheels are mounted in working position.
8. Dismounted tine arms are fastened to the rotor (see page 25).
9. Warning panels are adjusted to 3 m width.




Fig. 3-3

Fig. 3-3 Mounting of support wheels

3. MOUNTING OF THE MACHINE AFTER DELIVERY

Mounting of tine arms:




Fig. 3-4

Fig. 3-4 Pre-mounted tine arms (2) are screwed onto the hub (1) (hexagonal screws M12x40 and 12x35, locknut M12).

Caution! Be aware of the direction of rotation of the rotors! See drawing!

After mounting of the tine arms it must be checked that the tine arms on the innermost and the outermost rotors are exactly opposite each other.

When the machine has been assembled, the PTO shaft can be connected.



The slip clutch must be positioned on the machine end.

The lock-pin on the PTO shaft must be properly engaged in the spline on the machine's drive shaft!

ADJUSTMENT OF PTO DRIVE SHAFT

It may be necessary to shorten the PTO shaft from tractor to machine in order to prevent it bottoming out in the shortest position. On tractors with a short distance from PTO to link arm connection, the PTO shaft may be too long.



Important: The profile tubes must have minimum 200 mm overlap! In the shortest position there must be a distance of minimum 40 mm from profile tube to universal joint!

The adjustment of the PTO drive shaft takes place as follows:

- The tedder and the tractor are placed in the position in which the PTO shaft has the shortest length (e.g. during turning).
- The two PTO shaft half parts are separated.
- The one half part is pushed onto the tractor PTO, the other half part onto the drive shaft of the tedder.
- See the instruction manual for the PTO drive shaft for further instructions.



If the tedder is going to be connected to different tractors, it is important to make sure that the 200 mm overlap and the distance of 40 mm are observed. For tractors with very different distances between PTO and link arm connection it is recommendable to have different PTO shafts available.



After the adjustment the swivel area and clearance of the PTO shaft must be checked! The PTO shaft should not in any position get in contact with machine parts.

MOUNTING OF OPTIONAL EQUIPMENT

SUPPORT WHEEL

Mounting of this equipment is shown in the supplied spare parts book.




Fig. 3-5

Fig. 3-5 The support wheel is mounted on the plate above the left hitch pin. The desired height is adjusted with the spring pin (1) and fixed with the ring screw (2) to avoid vibrating.

3. MOUNTING OF THE MACHINE AFTER DELIVERY

ANTI-WRAPPING PLATE

Mounting of this equipment is shown in the supplied spare parts book.

NIGHT SWATH GEARBOX



Fig. 3-6

Fig. 3-6 Mounting of this equipment is shown in the supplied spare parts book.

- The standard protection on the centre gearbox is dismantled and the swath gearbox is pushed onto the spline shaft.
- The night swath gearbox is secured with clamping screw.
- The PTO shaft is pushed onto the offset spline shaft.
- It must be checked that there is enough space between the protection and the tine arms.

FUNCTIONAL TEST

After the preparation of the machine, a functional test must be carried out.



Incorrect mounting of the machine is highly dangerous. Before the functional test is carried out, please check that everything is mounted correctly according to the instructions in the manual and the mounting guide.

Make sure that there are no tools in the area around the machine!

Make sure that there are no persons in the danger zone!

After 5 hours of operation all screws must be re-tightened to ensure a safe operation!

4. MOUNTING OF THE TEDDER / PREPARATION



- Always disengage the PTO drive shaft before maintaining, repairing and mounting. Stop the engine and remove the ignition key. Secure the tractor and the rotary tedder so that they cannot move!
- The maximum number of revolutions is 540 rpm.
- Operating parts such as cords, hydraulic hoses and cables must be placed so that unintended operation and contact with the tractor wheels are impossible. Danger!
- During raising and lowering never stand between the tractor and the tedder or under the raised rotor arms. Risk of personal injury!
- Before starting the PTO check that there are no persons in the danger zone of the rotary tedder. Danger!
- Before work and transport on public roads always make sure that all guards are mounted correctly and locked where appropriate! Check that the lighting equipment is working.
- The operator should never leave the tractor during working! Make sure that there are no persons in the danger zone!

SPECIAL INSTRUCTIONS



In the area of the 3-point suspension there is a risk of personal injury since there are places where you can get jammed or cut!




Fig. 4-1

Fig. 4-1 Be particularly careful during connection and disconnection of machines! Never stand between the tractor and the tedder during connection to the link arms. The operator should not step into the danger zone until the electric cables, the hydraulic hoses and the PTO are to be connected. The operating elements of the tractor must be secured against unintended use before connection and disconnection.

PREPARATION OF TRACTOR

3-POINT SUSPENSION ON THE TRACTOR



Fig. 4.2

Fig. 4-2 The rotary tedder Z 8805 is designed to be connected to the 3-point suspension of the tractor - category II. Depending on the equipment of the tractor, balls can be installed.



The sideways movement of the link arms on the tractor must be minimised in order to avoid oscillation of the machine during work and transport. Therefore the link arms must be secured with limiting chains or other locking device.




Fig. 4-3

Fig. 4-3 Adjust the link arms of the tractor so that they are at the same height above the ground at both sides.

4. MOUNTING OF THE TEDDER / PREPARATION

PLACEMENT OF CORD

It should be possible to operate the cord for the locking pawl from the tractor seat. It must be ensured that it does not get jammed and is not placed on sharp edges. The cord must be relieved when the pawls are lowered.

HYDRAULIC SYSTEM (RESTRICTION)

The lifting cylinders of the rotary tedder are equipped with restrictors. No adjustments should be made on the tractor.

ELECTRIC SYSTEM

The lighting system (option) is equipped with a 7-pole plug for the trailer socket.

CONNECTION OF THE ROTARY TEDDER TO THE TRACTOR



The instructions are based on a fully mounted rotary tedder in locked transport position with the support folded down.

CONNECTION TO THE LINK ARMS AND TOP LINK OF THE TRACTOR



- **Never stand between the tractor and the tedder during connection to the tractor.**
- **Make sure that there are no persons in the swivel area of the rotor arms!**
- Reverse the tractor to the tedder and connect the balls on the pins on the suspension of the tedder to the link arms of the tractor and secure.
- Fold down the top link on the tractor and connect it to the upper ball on the suspension of the tractor and secure.



The top link bolt must be secured with spring pin. The chain of the spring pin must hang freely. The link arm balls must be secured with linch pin (size 12).

4. MOUNTING OF THE TEDDER / PREPARATION



Fig. 4-4

Fig. 4-4 Raise the machine with the link arms until the support is raised from the ground.

- Release the support by pulling out the spring pin (1).
- Move the support 90° to the rear and lock it again with the spring pin




Fig. 4-5

Fig. 4-5 Make sure that the transport safety bolt is pushed in! This is done by briefly pulling the transport safety bolt (2) and turning it so that the split pin is released. Push the transport safety bolt so far in that the split pin reaches the end of the guide. The spring supports the procedure and prevents the transport safety bolt from wandering back.

4. MOUNTING OF THE TEDDER / PREPARATION



Fig. 4-6

Fig. 4-6



When the tedder is lifted with the rear hydraulics, the rear window of the tractor must be closed.

If the rear window is open there is a risk that the machine parts will damage the rear window.

HYDRAULIC CONNECTION

For the conversion from transport to working position the rotary tedder Z 8805 needs a double-acting outlet.

For clearing of field boundaries, an additional single acting outlet is needed.

The stop valve on the machine side (ball valve) should be opened after the connection to the tractor hydraulics so that the coupling is not under pressure. When the machine is parked the pressure may adjust, for instance if the outdoor temperature changes.

CONNECTION OF LIGHTING EQUIPMENT

The lighting system is equipped with a 7-pole plug at the lighting cable. Connect this plug to the socket at the rear of the tractor.



After the connection the function of the lighting system must be checked! Dirt and moisture may result in contact problems or even short circuit. Therefore the plug connection must be kept clean and dry. Also check the tractor fuses for the 7 pin socket are in place and intact.

CONNECTION OF PTO SHAFT



The description implies that the length of the PTO shaft is adjusted to the tractor according to chapter 3: “Adjustment of PTO drive shaft.”

If the machine is used with different tractors it must be checked that the PTO shaft has the correct length.

On the tractor and machine side there must be an intact guard.

Only use the supplied PTO shaft or a PTO shaft that is approved by the manufacturer!

- Release the PTO shaft from the support chain.
- Push the PTO shaft onto the tractor PTO until the locking balls are engaged.
- The guard of the PTO shaft must be fastened with safety chains on the tractor in order to avoid that it rotates.

DISCONNECTION AND PARKING OF THE ROTARY TEDDER



Fig. 4-7

Fig. 4-7

- Raise the machine with the link arms.
- The front and the rear support are folded down and locked with the spring pin.
- Lower the machine with the link arms until it stands firmly with the wheels and the support on the ground.
- The hydraulic hoses are disconnected when the hydraulic system on the tractor and the machine side are not under pressure.
- Disconnect the PTO shaft from the tractor and place it in the support chain.
- Disconnect the electric cable for the lighting equipment from the tractor and place it on the machine.
- Disconnect the top link and the link arms from the machine.
- Fold up the top link and secure it on the tractor.
- Lower the link arms further.
- Drive the tractor forward, away from the machine.



Make sure that the machine is placed on firm and even ground so that it is not in danger of turning over.

Make sure that the transport safety bolt is still pushed in while the machine is parked.

Do not pull out the transport safety bolt when the machine is parked! Risk of personal injury! The shock absorber would press the suspension forward.

TRANSPORT ON PUBLIC ROADS



- During transport on public roads the current traffic rules in the country in question must be observed! This also applies to the rules regarding lighting and warning panels.
- Check that the transport safety bolt is pushed in correctly.
- The stop valves of the hydraulic system must be closed.
- During transport the top link must not be connected in the oblong hole on the 3-point linkage. There is a risk that the machine tips forward!
- Always adjust the driving speed to the conditions of the road. Drive carefully on bad roads and streets to ensure that the connection forces between the tractor and the machine do not cause damage.
- Driving, steering and braking capacity of the tractor are influenced by mounted implements and ballast weights! Be aware of the instructions from the tractor manufacturer and the supplement in chapter 10.
- When turning pay attention to the overhang and oscillating weight of the machine.

5. HANDLING OF THE TEDDER DURING WORKING



The following description implies that the tedder is completely mounted according to chapter 3 and connected to the tractor according to chapter 4. The machine is in transport position.

CONVERSION OF THE TEDDER FROM TRANSPORT TO WORKING POSITION



- For conversion from transport to working position, the machine is placed on even ground or uphill. Avoid slopes where the tractor and the machine may slide down or overturn. The side arms may swivel out uncontrolled whereby the machine might get damaged.
- When placing the machine on slopes, the risk of overturning and personal injury is increased.
- Make sure that there are no persons in the swivel and working area. There is danger of getting hit by the machine.

RELEASE OF THE TRANSPORT SAFETY BOLT




Fig. 5-1

Fig. 5-1 With raised machine the transport safety bolt is pulled towards the left to the end of the guide of the tightening pin (2). Finally the transport safety bolt is turned so that the tightening pin is engaged in the guide.

OPENING OF HYDRAULIC STOP VALVES




Fig. 5-2

Fig. 5-2 The stop valves of the hydraulic system are opened.

UNFOLDING THE MACHINE IN WORKING POSITION

- Slowly lower the machine on the middle rotor wheels with the rear hydraulics.
- With the double-acting outlet the machine is unfolded in a smooth movement. In working position the hydraulic cylinders must be fully extended. During working the outlet must stay in the position "Neutral". Do not pull the cord while the machine is being unfolded.



The side arms must be unfolded in a smooth movement.

In case of malfunction, the side arms are folded again and the procedure is repeated with increased number of rpm.

STARTING THE ROTOR



- Check that there are no persons near the machine before starting the rotor!
- Always start the PTO of the tractor with the engine at idle speed!

POSITION WHEN DRIVING ON HEADLANDS



Fig. 5-3

Fig. 5-3 The rotary tedder has a defined position for driving of headlands. In this position the rotors are lifted so much that the outermost rotors do not touch the ground. The hydraulic outlet on the tractor is activated in direction “raise” until the stop of the locking pawls (1) is in contact with the hydraulic cylinders at front. The locking pawls should not be raised with the cord!

SPREADING FROM FENCE

With the spreading from fence feature the machine can be placed in an offset position to the right or left. During spreading from fence the machine runs in an offset position behind the tractor which means that the crop is not thrown out to the field boundary.




Fig. 5-4

Fig. 5-4 During working the machine is placed in the offset position with the single-acting outlet.

5. HANDLING OF THE TEDDER DURING WORKING




Fig. 5-5

Fig. 5-5 For normal tedding the wheels are returned to middle position.



When avoiding obstacles or driving along fences there must be enough distance to the rotors!

CONVERSION OF THE TEDDER FROM WORKING TO TRANSPORT POSITION




- For conversion from working to transport position, the machine is placed on even ground or uphill. Avoid slopes where the tractor and the machine may slide down or overturn.
- When placing the machine on slopes, the risk of overturning and personal injury is increased.
- Make sure that there are no persons in the swivel and working area.

FOLDING TO TRANSPORT POSITION



Place the machine with all rotor wheels firmly on the ground. Disconnect the PTO!



PR14-0304

Fig. 5-6

Fig. 5-6 Pull the cord (1) for lifting the locking pawls (2) until the stop is reached. Afterwards activate the outlet on the tractor in direction “raise”. Hold the cord until the outermost arms have been folded in and the tension in the cord yields. Fold the machine further in to the final transport position.

CLOSING OF HYDRAULIC STOP VALVES




Fig. 5-7

Fig. 5-7 The stop valves of the hydraulic system are closed.

ACTIVATING THE TRANSPORT SAFETY BOLT




Fig. 5-8

- Fig. 5-8** Lift the tedder with the link arms until the wheels are raised from the ground.
- Briefly pull the transport safety bolt (2) and turn it so that the split pin (1) is released.
 - Push the transport safety bolt so far in that the split pin reaches the end of the guide. The spring supports the procedure and prevents the transport safety bolt from wandering back.

The rotary tedder is now ready for transport!



- In order to obtain safe transport, the steering and braking capacity of the tractor must be maintained in spite of the mounted machine. In this connection the instructions of the tractor manufacturer should be observed.
- It may be necessary to ensure a better weight distribution to the front axle.
- This can be checked by means of chapter 10.

6. BASIC ADJUSTMENT OF THE TEDDER



- When the basic adjustment is made, the PTO must be disconnected!
- The tractor engine must be stopped!
- Never work under the rotors without sufficient support!

ADJUSTMENT OF WORKING DEPTH

The distance of the tines to the ground is adjusted in working position with the top link of the tractor.




Fig.6-1

Fig. 6-1

The machine is aligned by driving forward briefly.

- Stop the tractor engine and secure the tractor.
- Adjust the working depth with the top link so that the double tines touch the ground slightly.

Note:

- If the tines are adjusted too low, there is danger of contamination of the feed and damage to the grass roots. The tines are worn unnecessarily.
- If the tines are adjusted too high, clean raking cannot be obtained.
- The adjustment must be checked during the operation.

ADJUSTMENT OF THE WORKING DEPTH WITH EXTRA SUPPORT WHEEL (OPTION)

If the rotary tedder is equipped with a support wheel (option) at the suspension, the working depth is adjusted by means of this wheel.

With regard to the desired working depth, the same criteria apply as in chapter 6: ADJUSTMENT OF WORKING DEPTH.

Remember that the lever for adjustment of the link arms must be in floating position. The support wheel maintains the height.



During transport on the public roads the machine must be equipped with inflexible top link. Please note! Not in the oblong hole!

ADJUSTMENT OF SPREADING ANGLE



Fig.6-2

Fig. 6-2 The support wheels can be set to different spreading angles. The adjustment takes place by adjusting the wheel bracket on the wheel carrier.

The machine must be lifted to adjust the spreading angle.

The adjustment must take place in consideration of the conditions. The following usually applies:

6. BASIC ADJUSTMENT OF THE TEDDER




Fig.6-3

Fig. 6-3 Normal spreading angle = pos. N.




Fig.6-4

Fig. 6-4 Small spreading angle for dry material = pos. F.




Fig.6-5

Fig. 6-5 Big spreading angle = pos. S.

6. BASIC ADJUSTMENT OF THE TEDDER



All wheels must have the same adjustment!

If, for changing the spreading angle, another adjustment of the wheels is used than prescribed by the factory, the top link must also be adjusted - in order to ensure that the tines of the tedder are adjusted correctly for picking up the material.

ADJUSTMENT OF SHOCK ABSORBER




Fig.6-6

Fig. 6-6 The shock absorber (1) ensures a steady operation.




Fig.6-7

Fig. 6-7 From the factory the springs of the shock absorber are adjusted to 37 mm.



When driving on slopes under extreme conditions it may happen that the tines are lifted from the ground without picking up the grass.

In this case the springs must be tightened (to maximum 32 mm).

WORKING SPEED AND NUMBER OF REVOLUTIONS

The working speed and the number of rpm during tedding and swath spreading depend on the type and amount of crop, the dry matter content and the ground conditions.

The following can be used as a guide:

- PTO number of revolutions, approx. 400 - 540 RPM
- Driving speed, approx. 4 - 15 km/h

Both values must be adjusted to the working conditions.

DRIVING SPEED AND NUMBER OF REVOLUTIONS

Choose the driving speed at which the rotary tedder picks up the material completely. Choose the number of revolutions on the PTO at which the material is processed correctly.

This depends on the condition of the material, i.e. the drier the material, the lower the number of revolutions.

SPREADING OF MOWN SWATHS

You should drive so that there is a swath between the tractor wheels. The working speed depends on the condition of the material. The number of revolutions of the PTO must be about 540 rpm.

The swaths should be divided evenly in relation to the rotors so that the tractor does not drive on the material.

TEDDING

During tedding of spread material, you should work at a low number of rpm - but at a higher driving speed - in order to avoid loss of crop due to crumbling. Check whether the chosen relation between driving speed and number of revolutions gives the desired result. Adjust if necessary.

SPREADING OF SWATHS

You should drive so that there is a swath between the tractor wheels.

The number of rpm of the PTO should be so low that the swaths are spread with a very gentle treatment of the material.

The driving speed should be adjusted according to the result.

NIGHT SWATHS

With the swath gearbox mounted small single swaths are made at maximum 300 - 400 rpm on the PTO. The driving speed should be adjusted according to the result.



Do not cross the swaths. This would result in irregular load of the machine and a bad spreading pattern.

7. SERVICE AND MAINTENANCE OF THE TEDDER

SAFETY RULES



- Maintenance, service, cleaning and repair must only take place when the PTO and the engine have been stopped. Remove the ignition key!
- Take care that oil and grease do not get in contact with your skin.
- After the first hours of operation all screws must be re-tightened!

GENERAL MAINTENANCE INSTRUCTIONS



- To obtain high operational safety and minimum wear there are certain maintenance and service intervals which must be observed. This includes e.g. cleaning, greasing and lubrication of parts and components.
- Screws and nuts must be checked after every 50 hours of operation and re-tightened if necessary!
See the table for torque settings in chapter 2. MAINTENANCE.
It is particularly important to check the fixing bolts of the rake tines on the tine arms.
- Only use original spare parts and equipment. There is no warranty on non-original components. The manufacturer is not responsible for any damage resulting from such use.

CLEANING OF THE MACHINE AND PREPARATION FOR WINTER STORAGE

CLEANING OF THE MACHINE



- When cleaning with a high pressure cleaner never spray directly on bearings.
- After cleaning, all bearings must be greased carefully until grease comes out of the bearings to ensure that possible water is pressed out.
- When cleaning with high pressure the paint may be damaged. Therefore sufficient distance must be kept between the nozzle on the high pressure cleaner and the machine.
- Polished parts, e.g. piston rods, require thorough drying to avoid possible damage.

PLACEMENT OF THE MACHINE IN THE OPEN

- If the tedder is placed in the open for a longer period, all bearings must be greased according to the lubrication schedule.
- Parts polished such as piston rods of the hydraulic cylinders must be cleaned and brushed with grease to protect against wind and weather.

WINTER STORAGE

- Check the tedder for damaged parts, loose screw-joints and leakage. If there is any damage it may be forgotten during the winter and result in problems the following year. Therefore the machine must be checked carefully before the winter storage.
- Grease the tedder according to the lubrication chart.
- Clean the machine carefully.
- The machine must be stored in a place where it is protected against wind and weather in the best possible way.
- Parts polished with use must be greased to protect against rust.
- The PTO shaft is dismantled and the inner and outer tubes are separated. Grease the sliding surfaces and reassemble.

WHEELS



- **The wheels must be checked regularly for damage and correct tyre pressure.**
- **Wheel-fixing bolts must be checked regularly and re-tightened if necessary!**
- **Repair of wheels should only be made by experts and with correct tools!**
- **Mounting of wheels requires correct mounting tools and must be performed by persons with sufficient knowledge.**
- **When working with the wheels the tedder must be secured so that it cannot move!**

TYRE PRESSURE



The tyre pressure must be checked regularly and adjusted if necessary. The required tyre pressure is shown in the below table:

	Wheels	Tyre pressure (bar)
Rotor wheels	18.5-8.50-8 (6PR)	2.5
Rotor wheels	16-6.50-8 (6PR)	1.5
Extra support wheel (option)	16-6.50-8 (6PR)	1.5

Caution: If the pressure is too high the tyres may crack. If the pressure is too low the tyres may be damaged due to deformation of the tyre wall.

PTO SHAFTS



When working with the PTO shafts:

- **Stop the engine!**
- **Remove the ignition key!**

INSTRUCTIONS REGARDING PTO SHAFTS:

- Never use PTO shafts without guards or if guards are damaged. Risk of personal injury!
- Missing or damaged protection tubes and covers must be replaced immediately!
- Only use PTO shafts that are approved by the manufacturer!
- Grease the PTO shafts carefully according to the lubrication chart.

HYDRAULIC SYSTEM



- **Liquids under pressure can penetrate the skin. Danger of infection!**
- **In case of personal injury caused by oil under pressure, consult a doctor immediately.**
- **After the first 10 hours of operation all hydraulic screw joints must be re-tightened.**
- **Before working with the tedder all hydraulic hoses must be checked for wear and damage.**
If hydraulic hoses are worn or damaged they must be replaced immediately.

Hydraulic hoses have a natural aging. They are marked with date of production. The law prescribes that hydraulic hoses are replaced after 6 years.

Only use original spare parts when replacing!

When working with the hydraulic system make sure that it is not under pressure!

The rotors of the tedder must stand firmly on the ground!

8. MAINTENANCE - GREASE CHART



- Maintenance, service, cleaning and repair must only take place when the PTO and the engine have been stopped. Remove the ignition key!
- Take care that oil and grease do not get in contact with your skin!
- During greasing the rotary tedder must be in working position and parked safely and firmly on the ground!

This chapter describes all grease points as well as service intervals. The observance of the following instructions is a precondition for the operational safety and long life of the machine.

PTO SHAFT

The rotary tedder is equipped with a PTO shaft with overload protection.




Fig.8-1

Fig. 8-1 The grease spots on the PTO shaft must be greased with universal grease according to the intervals indicated.

See also the instruction manual for the PTO drive shaft.



GEARBOXES

The centre gearbox and the rotor gearboxes are maintenance-free. The oil level should only be checked if there is a noticeable loss of oil with the machine in horizontal position.




Fig.8-2

Fig. 8-2 Centre gearbox:

Oil level:	1.2 litres
Quality:	SAE 90 API-GL-4




Fig.8-3

Fig. 8-3 Rotor gearbox:

Fluid grease:	0.2 kg
Quality:	Shell Alvania EP




Fig. 8-4

Fig. 8-4 Fingerclutch:
Graphitegrease:
Quality:

Molykote BR2 Plus

GREASE SPOTS ON THE TEDDER

JOINTS




Fig.8-5

- Fig. 8-5 1. Hinge pins - 25 hours**
12 grease points




Fig.8-6

- Fig. 8-6 2. Joint piece - weekly / 50 hours**
4 grease points
- 3. Boom arm - weekly / 50 hours**
4 grease points

8. MAINTENANCE - GREASE CHART




Fig.8-7

Fig. 8-7 4. Steering rod - weekly / 50 hours
4 grease points

OBLONG HOLE (GUIDE)




Fig.8-8

Fig. 8-8 5. Oblong hole - weekly / 50 hours
4 grease points

HEADSTOCK




Fig.8-9

Fig. 8-9 6. Hinge pin - weekly / 50 hours
1 grease point

TRANSPORT SAFETY BOLT




Fig.8-10

Fig. 8-10 7. Transport safety bolt - monthly / 200 hours

The guides of the transport safety bolt and the tightening pin must occasionally be lubricated with oil.

This ensures that the transport safety bolt keeps working optimally.

GREASE CHART OVERVIEW




Fig.8-11

Fig. 8-11 The following plant-based oil and grease types can be used:

- **Grease:**
PLANTOGEL 2-S
- **Oil:**
PLANTOHXTRAC



Drained oils must be handed over to a recycling company!

9. MACHINE DISPOSAL

When the machine is worn-out it must be disposed of in a proper way. Observe the following:

- The machine must not be placed somewhere outside; it must be emptied of oil (gearboxes and hydraulic system). These oils must be handed over to a recycling company.
- Disassemble the machine and separate the individual parts, e.g. tyres, hydraulic hoses, hydraulic valves etc.
- Hand over the usable parts to an authorised recycling centre. The large scrapping parts are handed over to an authorised breaker's yard.

10. SUPPLEMENT

Translation from Norm EN ISO 4254-10

Supplement C (informative)

Stability with the combination tractor – rotary tedder and rake

This supplement concerns 6.1.f) in this part of ISO 4254 which deals with the requirement of informing of possible loss of the tractor's stability due to the connection of the machine.


The following text is a suggestion to the manufacturer with the purpose of making it possible for him to provide suitable and complete information.

The example concerns a rotary tedder and rake connected to a tractor.

Due to the own weight of the machine, the combination tractor – rotary tedder and rake can become unstable. In order to test the total stability the following formula can be used for the calculation of the minimum front ballast $I_{F,min}$ at a minimum front axle load of 20% of the tractor's own weight:

$$I_{F,min} = \frac{(I_R \times (c + d)) - (T_f \times b) + (0,2 \times T_E \times b)}{a + b}$$

ANNOTATION In this calculation rear-mounted implements and front/rear combinations have been taken into consideration.



List of signs

T_E [kg]	The tractor's own weight	1)
T_F [kg]	Front axle load with empty tractor	1)
T_R [kg]	Rear axle load with empty tractor	1)
I_R [kg]	Total weight rear-mounted implement/rear ballast	2)
I_F [kg]	Total weight front-mounted implement/front ballast	2)
a [m]	Distance between centre of gravity front-mounted implement/front ballast and middle of front axle	2) 3)
b [m]	The tractor's wheel distance	1) 3)
c [m]	Distance between middle of rear axle and middle of link arm balls	1) 3)
d [m]	Distance between middle of link arm balls and centre of gravity rear mounted implement/rear ballast	2)

- 1) see instruction manual for the tractor
 2) see price list and/or instruction manual for the implement
 3) to be measured

Picture B.1 Example of references to stability of the combination tractor – rotary tedder and rake

11. WARRANTY

Your machine is warranted according to legal rights in your country and the contractual agreement with the selling dealer. No warranty shall, however, apply if the machine has not been used, adjusted and maintained according to the instructions given in this operator's manual.

It is prohibited to carry out any modifications to the machine unless specifically authorized, in writing, by a NEW HOLLAND representative.

EF-overensstemmelseserklæring/ EG-Konformitätserklärung/ EC Declaration of Conformity/ Déclaration CE de conformité/ Dichiarazione CE di conformità/ EG Verklaring van Overeenstemming/ EG-försäkran om överensstämmelse/ EY-vaatimustenmukaisuusvakuutus/ Declaración de conformidad CE/ Deklaracja Zgodności WE./ Декларация за съответствие ЕО/ EK Megfelelősségi Nyilatkozat /ES Prohlášení o shodě/ EB Atitikties deklaracija/ ES prehlásenie o zhode/ Declarația de conformitate CE/ Vastavuse Deklaratsioon EÜ /ES Izjava o skladnosti/ Δήλωση πιστότητας ΕΚ/ Declaração de fidelidade CE/ Dikjarazzjoni ta' Konformità tal-KE/ EK Atbilstības deklarācija/

Fabrikant/ Hersteller/ Manufacturer/ Fabricant/ Produttore/ Fabrikant/ Fabrikant/ Valmistaja/ Fabricante/ Producent/ Производител/ Gyártó/ Výrobce/ Gamintojas/ Výrobca/ Producător/ Tootja/ Proizvajalec/ Κατασκευαστής/ Fabricante/ Fabbrikant/ Ražotājs

CNH INDUSTRIAL BELGIUM N.V.

Leon Claeyssstraat 3a, 8210 Zedelgem, BELGIUM

Repræsenteret af Antoon Vermeulen, Leon Claeyssstraat 3A, B8210 Zedelgem (Belgien), som også har tilladelse til at indsamle teknisk dokumentation / vertreten durch Antoon Vermeulen, Leon Claeyssstraat 3A, B8210 Zedelgem (Belgium), der auch autorisiert ist, die technische Akte zu erarbeiten / represented by Antoon Vermeulen, Leon Claeyssstraat 3A, B8210 Zedelgem (Belgium), who is also authorised to compile the Technical File / Réprésentés par Antoon Vermeulen, Leon Claeyssstraat 3A, B8210 Zedelgem (Belgique), également autorisé à constituer le dossier technique / rappresentati da Antoon Vermeulen, Leon Claeyssstraat 3A, B8210 Zedelgem (Belgio), autorizzato a compilare il File tecnico / vertegenwoordigd door Antoon Vermeulen, Leon Claeyssstraat 3A, B8210 Zedelgem (Belgium), die tevens is gemachtigd om het Technisch Bestand samen te stellen / representerade av Antoon Vermeulen, Leon Claeyssstraat 3A, B8210 Zedelgem (Belgien), som också har behörighet att sammanställa den tekniska dokumentationen / edustajamme Antoon Vermeulenin, osoite Leon Claeyssstraat 3A, B8210 Zedelgem (Belgium) välityksellä, jolla on myös oikeus laatia tekninen tiedosto / representados por Antoon Vermeulen, Leon Claeyssstraat 3A, B8210 Zedelgem (Bélgica), quien además está autorizado para recopilar el documento técnico / której przedstawicielem jest Antoon Vermeulen, Leon Claeyssstraat 3A, B8210 Zedelgem (Belgia), który jest również upoważniony do sporządzania dokumentacji technicznej / представлявани от Антоон Вермюлен, Леон Клаейсstraat 3A, B8210 Zedelgem (Белгия), с упълномощение също да състави Техническото досие / akiket képvisel: Antoon Vermeulen, Leon Claeyssstraat 3A, B8210 Zedelgem (Belgium), aki szintén jogosult a műszaki dokumentumok összeállítására / v zastoupení Antoon Vermeulen, Leon Claeyssstraat 3A, B8210 Zedelgem (Belgium), s autorizací k tvorbě technického souboru / atstovaujami Antoon Vermeulen, Leon Claeyssstraat 3A, B8210 Zedelgem (Belgija), taip pat turintis teisę sudaryti technines bylas / v zastúpení Antoonom Vermeulenom, Leon Claeyssstraat 3A, B8210 Zedelgem (Belgicko), ktorý je oprávnený zostavovať technickú dokumentáciu / reprezentati de Antoon Vermeulen, Leon Claeyssstraat 3A, B8210 Zedelgem (Belgia), care este, de asemenea, autorizat să compileze dosarul tehnic / esindajatega Antoon Vermeulen, Leon Claeyssstraat 3A, B8210 Zedelgem (Belgia), kellel on samuti luba tehnilise faili koostamiseks / ki nas zastopa Antoon Vermeulen, Leon Claeyssstraat 3A, B8210 Zedelgem (Belgija), ki je pooblaščen tudi za sestavo tehnične dokumentacije / εκπροσωπούμενοι από τον Antoon Vermeulen, Leon Claeyssstraat 3A, B8210 Zedelgem (Βέλγιο), με εξουσιοδότηση και για τη σύνταξη του Τεχνικού φακέλου / representados por Antoon Vermeulen, Leon Claeyssstraat 3A, B8210 Zedelgem (Bélgica), que também tem autorização para compilar o Ficheiro Técnico / irraprezentata minn Antoon Vermeulen Leon Claeyssstraat 3a, B8210 Zedelgem (Belġju), min huwa wkoll awtorizzat li tiġbor l-Fajl Tekniku / Antoon Vermeulen, Leon Claeyssstraat 3A, B8210, Zedelgem (Belgium), pārstāvēti, kas ir pilnvarots arī sastādīt tehnisko reģistru

Erklærer hermed, at/ Erklären hiermit, daß/ Hereby declare that/ Déclare par la présente que/ Dichiaro che/ Verklaren hierbij dat/ Försäkrar härmed, att/ Vakuuttaa täten, että tuote/ Por el presente declara que/ Niniejszym deklaruje, że/ Декларирам, че/ Az alábbiakban kijelentem, hogy/ Tímto prohlašuje, že/ Deklaruoja, kad/ Týmto prehlasujeme, že/ Prin prezenta declar că/ Alljärgnevaga deklareerib, et/ Izjavljamo, da je/ Με το παρόν δηλώνω ότι/ Abaixo declara que / Jiddikjaraw li / Apstiprinu, ka

Maskine:	La máquina:	Masin:
Maschine:	Maszyna:	Stroj:
Machine:	Машината:	Η μηχανή:
Machine:	Gép:	Máquina:
La macchina:	Stroj:	Il-magna:
Machine:	Mašina:	Mašina:
Maskin:		Stroj:
Laite:		Mašina:



Model/Type: **Z 8805**
Designation: Tedder
Serial:


- er i overensstemmelse med Maskindirektivets bestemmelser (Direktiv 2006/42/EF) og hvis relevant også bestemmelserne i EMC-direktivet 2014/30/EU.

- In übereinstimmung mit den Bestimmungen der Maschinen-Richtlinie 2006/42/EG und wenn erforderlich auch mit der EMC-Richtlinie 2014/30/EU hergestellt wurde.

- is in conformity with the provisions of the Machinery Directive 2006/42/EC and if relevant also the provisions of the EMC Directive 2014/30/EU.


- est conforme aux dispositions de la Directive relatives aux machines 2006/42/CE et également aux dispositions de la Directive sur la Directive EMC 2014/30/UE.
- é in conformita' con la Direttiva Macchine 2006/42/CE e, se pertinente, anche alla Direttiva alla Direttiva EMC 2014/30/UE.
- in overeenstemming is met de bepalingen van de Machine richtlijn 2006/42/EG en wanneer relevant ook met de bepalingen van de EMC richtlijn 2014/30/EU.
- är i överensstämmelse med Maskindirektivets bestämmelser (Direktiv 2006/42/EG) ock om relevant också bestämmelserna EMC-direktivet 2014/30/EU.
- täyttää Konedirektiivin (Direktiivi 2006/42/EY) määräykset ja oleellisilta osin myös EMC-direktiivin 2014/30/EU.
- es conforme a la Directiva de Maquinaria 2006/42/CE y, si aplica, es conforme también a la Directiva EMC 2014/30/EU.
- pozostaje w zgodzie z warunkami Dyrektywy Maszynowej 2006/42/WE i jeżeli ma to zastosowanie również z warunkami Dyrektywy dot. kompatybilności elektro magnetycznej EMC 2014/30/UE.
- отговаря на изискванията на Директивата за Машините 2006/42/ЕО и ако има приложение на изискванията на Директивата за електромагнитна съвместимост 2014/30/EC.
- Megfelel a 2006/42/EK Gépi Eszközökre vonatkozó előírásoknak és amennyiben felhasználásra kerül, a 2014/30/EU Elektromágneses kompatibilitás Irányelv feltételeinek.
- odpovídá základním požadavkům Strojní směrnice 2006/42/ES a jestliže to její uplatnění vyžaduje i s podmínkami Směrnice 2014/30/EU týkající se elektromagnetické kompatibility.
- atitinka Mašinų direktyvos Nr. 2006/42/EB ir, jeigu taikoma, Elektromagnetinio suderinamumo direktyvos Nr. 2014/30/ES reikalavimus.
- je v súlade s podmienkami Smernice 2006/42/ES o strojných zariadeniach a pokiaľ si to jeho uplatnenie vyžaduje aj s podmienkami Smernice 2014/30/EÚ o elektromagnetickej kompatibilite.
- îndeplinește prevederilor Directivei de Mașini 2006/42/CE și dacă este utilizată de asemenea cu prevederile Directivei referitoare la compatibilitatea electro-magnetică EMC 2014/30/UE.
- on vastavuses Masinate Direktiivi tingimustega 2006/42/EÜ ning sammuti juhul, kui on tegemist sammuti on vastavuses Elektromagnetilise kokkusobivuse Direktiivitingimustega EMC 2014/30/EL.
- z določili Direktive o strojih 2006/42/ES ter, če je to relevantno, tudi z določili EMC Direktive 2014/30/EU.
- παραμένει σύμφωνη με τους όρους της Οδηγίας περί Μηχανών 2006/42/EK και σε περίπτωση που αυτό εφαρμόζεται και με τους όρους της Οδηγίας περί ηλεκτρομαγνητικής συμβατότητας (ΗΜΣ) 2014/30/ΕΕ.
- Está de acordo com exigências das Directivas das Maquinarias 2006/42/CE e no caso em que tiver igualmente aplicação com as exigências das Directivas referentes a compatibilidade electromagnética EMC 2014/30/UE.
- tikkonforma mad-dispożizzjonijiet tad-Direttiva dwar il-Makkinarju 2006/42/KE u jekk rilevanti wkoll mad-dispożizzjonijiet tad d-Direttiva EMC 2014/30/EU.
- atbilst mašīnu direktīvai 2006/42/EK, kā arī nepieciešamības gadījumā elektromagnētiskās saderības direktīvai EMC 2014/30/ES.

Zedelgem, date:



Antoon Vermeulen

Dealer's stamp



CNH Industrial Belgium N.V. reserves the right to make improvements in design and changes in specifications at any time without notice and without incurring any obligation to install them on units previously sold.

Specifications, descriptions, and illustrative material herein are as accurate as known at time of publication, but are subject to change without notice.

Availability of some models and equipment builds varies according to the country in which the equipment is being used. For exact information about any particular product, please consult your Kongskilde dealer.



© 2018 CNH Industrial Belgium N.V. All Rights Reserved.

Kongskilde is a trademark registered in the United States and many other countries, owned by or licensed to CNH Industrial N.V., its subsidiaries or affiliates.

Any trademarks referred to herein, in association with goods and/or services of companies, other than owned by or licensed to CNH Industrial N.V., its subsidiaries or affiliates, are the property of those respective companies.